


Flow chart of TSS/Bridge Alarm system



Notes:

- up to five IWACS system 02-WA(-W) acknowledgement pushbuttons can be connected;
- up to five DOACS 02-WB(-W) acknowledgement pushbuttons can be connected;
- up to seven BA-Panel-K cabin panels can be connected in the absence of "the second mate selection panel of DOACS" option and DOACS level 3 alarm connection;
- up to four cabin panels BA-Panel-K can be connected for DOACS 2 level 2 alarm in case of connection of 14Z buzzers for DOACS level 3 alarm and "the second mate selection panel of DOACS" option.